

PN ACC6

*Note: The foam inserts are used as spacers, to help the cabin filter fill the compartment. However, not all applications will need to use these inserts.*

*Please see photo below for an example of how the foam pieces are attached (if required for the vehicle application).*

